


2.1 CH Sound Bar TH-BY370A QUICK START GUIDE




Before using this soundbar, please read all safety information from the user manual.

RECOMMENDED PLACEMENT



Soundbar: Under the TV (if wall-mounted)/ In front of the TV
Subwoofer: On the floor, alongside the TV (or in the front corner of the room)




USING THE SOUNDBAR

1. Insert 2 x 'AAA' batteries into the remote control.
2. Set the ON/ OFF switch on the back of the unit to ON.
3. Press ON/ STANDBY on unit/ POWER button on remote control.
4. Press MODE button to select mode. The options are B/T, OPT, COA, AUX, FM and USB (if USB device is connected).

For more information, refer to the user manual or call Customer Support at 1300 366 155.

CONNECTING THE SOUNDBAR TO TV


1. Power connection: First connect the DC output of the power adaptor to the soundbar, then plug in to the AC power outlet.
2. Subwoofer to SW OUT
3. Connection to TV: COAXIAL Input on the soundbar to COAXIAL Output on TV



2

CONNECTING THE SOUNDBAR TO OTHER DEVICES

4. OPTICAL Input on the soundbar to OPTICAL Output of other devices (Blu-ray/ DVD player/ Gaming consoles)
5. Other audio sources: Bluetooth/ USB/ Aux



3